

## **User guide**

### **Octans Subsea**

### **Models 1000, 3000 and 3000Ti**

IXSEA S.A.S. – Site de Marly  
55, avenue Auguste Renoir  
78160 MARLY-LE-ROI – France  
Tel : +33 (0)1 30 08 98 88  
Fax : +33 (0)1 30 08 88 01

IXSEA S.A.S. – Site de Brest  
Rue Rivoalon, Sainte-Anne du Portzic  
29200 BREST – France  
Tel : +33 (0)2 98 05 67 00  
Fax : +33 (0)2 98 45 70 71

## TABLE OF CONTENTS

TABLE OF CONTENTS .....	2
FOREWORD .....	5
RIGHTS .....	6
WARRANTY .....	7
CUSTOMER SUPPORT .....	8
EXPORT .....	9
Shipping pack contents .....	10
1 INTRODUCTION .....	11
2 TECHNICAL DESCRIPTION .....	12
3 MECHANICAL INTERFACE .....	14
4 ELECTRICAL INTERFACE .....	15
4.1 Description of the top panel .....	15
4.2 Listing of interfaces .....	16
4.3 Description of the 16-pin connector .....	16
4.4 Power supply (pins 1, 2) .....	17
4.5 Configuration and display output (pins 12, 14, 15, 16) .....	18
4.6 Analogue Outputs (pins 7, 8, 9, 11, 13) .....	19
4.7 Digital Input/Output (pins 3, 4, 5, 6 and 10) .....	20
4.7.1 RS 232 Input / Output .....	21
4.7.2 RS 422 Input/ Output .....	22
5 OPERATIONAL CONSIDERATIONS .....	23
5.1 Heading error due to the speed log .....	23
5.2 Incorrect latitude data .....	24
5.2.1 Amplitude of error due to latitude data .....	24
5.2.2 Sensitivity to unreliable latitude data .....	24
6 COMPUTATION OF HEAVE, SURGE, AND SWAY .....	25
6.1 Definition of heave, surge, and sway .....	25
6.2 Axis directions for heave, surge and sway measurements .....	25
6.2.1 General .....	25
6.2.2 Sign conventions .....	26
6.3 Description of the heave filter .....	26
6.4 Use of lever arms for heave computation .....	27
6.4.1 Multiple lever arms .....	27
6.4.2 Effect of a lever arm on the computation of heave .....	29
7 TRUE HEADING, ROLL AND PITCH .....	31
7.1 Roll .....	31
7.2 Pitch .....	32

APPENDIX A-SPECIFICATION .....	33
1. TECHNICAL DESCRIPTION .....	33
1.1. Performance.....	33
Gyrocompass Technical Performance .....	33
Motion Sensor Technical Performance .....	33
1.2. Environmental specifications .....	34
1.3. Interface .....	34
1.3.1 Power Requirement.....	34
1.3.2 Outputs .....	34
1.3.3 Inputs .....	34
1.3.4 Repeater Software.....	35
1.4. Housings .....	35
1.4.1. Surface unit.....	35
1.4.2. Subsea units .....	35
1.4.3 Useable configuration .....	36
2. CERTIFICATION .....	36
APPENDIX B - PHYSICAL PRINCIPLES OF OCTANS .....	37
1. THE TECHNOLOGY OF FIBRE OPTIC GYROSCOPES (FOGs) .....	37
1.1. The Sagnac Effect.....	37
1.2. FOG description and performance .....	37
1.3. Inertial Measurement Unit (IMU).....	38
2. THE FIBRE OPTIC GYROCOMPASS – UNDERLYING PRINCIPLES.....	40
2.1. North finders.....	40
2.2. Gyrocompasses .....	41

**FIGURES**

Figure 1 : Subsea Octans unit opened..... 12

Figure 2 : Subsea Octans bottom plate mounting diagram..... 14

Figure 3 : Subsea Octans top panel..... 15

Figure. 4 : Heading error in degrees by secant of latitude ..... 24

Figure 5 : Axis directions for the heave, surge, and sway measurements ..... 25

Figure 6 : Subsea Octans lever arm reference point ..... 27

Figure 7: Multiple lever arms monitoring ..... 28

Figure 8 : Effect of lever arms ..... 29

Figure 9 : Definition of the lever arms vector for heave computation..... 30

Figure 10 : Definition of true heading ..... 31

Figure 11 : Definition of roll ..... 31

Figure 12 : Definition of pitch..... 32

Figure B1 : The “heart” of a FOG the optical fiber coil with its integrated optical circuit..... 38


Figure B2: North Finder / basic concept..... 41

Figure B3: Conical movement of the local gravity  $g$  in relation to the Inertial Space..... 42

## FOREWORD

This document serves as the user guide for the subsea versions, model 1000, 3000 and 3000Ti, of the Gyrocompass and Motion Sensor Octans developed and manufactured by IXSEA.

<b>Version</b>	<b>Date</b>	<b>Comment</b>
/	October 1999	First issue
A	January 2000	Modification of figure 2
B	August 2000	Modification of figure 3 Modification of connector diagram
C	August 2001	General text review Support multiple lever arms (firmware 4.1 and later)
D	February 2003	Logo update and addition of 3000Ti model
E	January 2004	Heave and interface update
F	March 2004	Logo and list of contacts update


 IXSEA	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

## RIGHTS

*All IXSEA products, including FOG technology, are protected by patents that have either already been issued or which have been formally applied for. The information contained in this manual supersedes all previously published information. IXSEA reserves the right to change prices and technical specifications without notice.*

*Octans™ is a trademark registered by IXSEA S.A.S.*

*Printed in France by IXSEA S.A.S., 55, Avenue Auguste Renoir, F-78160 Marly-le-Roi.*

 IXSEA	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

## WARRANTY

IXSEA provides a warranty covering this product against any defect in materials or manufacture for a period of two (2) years from the date of shipment. In the event that such a defect becomes apparent during the stipulated warranty period, IXSEA undertakes, at its sole discretion, either to repair the defective product, bearing the cost of all parts and labor, or to replace it with an identical product.

In order to avail itself of the present warranty, Customer must notify IXSEA of the defect before expiry of the warranty period and take all steps necessary to enable IXSEA to take the required action. Customer shall be responsible for the packaging and shipment of the defective product for delivery to the repair center notified by IXSEA, the cost of such shipment being borne by Customer. IXSEA agrees to bear the cost of return shipment of product to Customer, who undertakes to pay all taxes, dues and expenses arising from such shipment.

This warranty shall not be construed as covering defects, malfunctions or damage caused by improper use or inadequate maintenance of the product. Under no circumstances shall IXSEA be obligated to provide repair or replacement under this warranty in order a) to repair damage caused by work done by any person not representing IXSEA for the installation, repair or maintenance of the product ; b) to repair damage caused by improper use or connection to incompatible equipment, and specifically, **the opening of the housing of the equipment under warranty shall cause the warranty to be automatically cancelled** ; c) to maintain any product that has been modified or integrated into a larger configuration, if such modification or integration increases the duration or difficulty of the maintenance of said product.

**This warranty covers the product hereunder and is provided by IXSEA in place of all and any other warranty whether explicit or implicit. IXSEA does not guarantee the suitability of the product under warranty for sale or any specific use. IXSEA's liability is limited to the repair or replacement of defective products, this being the sole remedy open to Customer in the event the warranty becomes applicable. IXSEA cannot be held liable for indirect, special, subsequent or consequential damage, irrespective of whether IXSEA has or has not received prior notification of the risk of occurrence of such damage.**

## CUSTOMER SUPPORT

To obtain support or information on any of our products, you may :


- contact IXSEA Customer Support directly,
- by e-mail : [inertial.support@ixsea.com](mailto:inertial.support@ixsea.com)
- by phone through IXSEA 24/7 hot-line : +33 (0)1 30 08 98 98
- contact your local IXSEA representative :

Contact	phone	fax	e-mail
Ixsea SAS 55 avenue Auguste Renoir 78160 Marly le Roi FRANCE	+33 (0) 1 30 08 98 88	+33 (0)1 30 08 88 01	<a href="mailto:info@ixsea.com">info@ixsea.com</a>
Ixsea BV A. Hofmanweg 5A 2031 BH Haarlem THE NETHERLANDS	+31 (0) 23 750 51 10	+31 (0) 23 750 51 11	<a href="mailto:info@ixsea.com">info@ixsea.com</a>
Ixsea Ltd 6 West Shore Business Centre Long Craig Rigg West Shore Road Edinburgh EH5 1QT SCOTLAND	+44 131 552 03 03	+44 131 552 66 19	<a href="mailto:info@ixsea.com">info@ixsea.com</a> <a href="mailto:sales-uk@ixsea.com">sales-uk@ixsea.com</a> <a href="mailto:kelso.riddell@ixsea.com">kelso.riddell@ixsea.com</a>
Ixsea- Inc 35 Corporate Drive 4 <sup>th</sup> floor Burlington MA 01803 USA	+1 781 685 46 32	+1 781 685 4798	<a href="mailto:info@ixsea.com">info@ixsea.com</a> <a href="mailto:hubert.pelletier@ixsea.com">hubert.pelletier@ixsea.com</a> <a href="mailto:richard.dentzman@ixsea.com">richard.dentzman@ixsea.com</a>
Ixsea Pte 53 UBI Avenue 1 #03-10 Paya Ubi Industrial Park 408934 SINGAPORE	+65 67 47 49 12	+65 67 4749 13	<a href="mailto:info@ixsea.com">info@ixsea.com</a> <a href="mailto:wilbert.degroot@ixsea.com">wilbert.degroot@ixsea.com</a>

*A detailed description of our products and a list of our representatives are available on our website:*

[www.ixsea.com](http://www.ixsea.com)




 IXSEA	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

## EXPORT

OCTANS is free for export and use worldwide, except in the following countries (list dated December 2002):

OCTANS cannot be exported or re-exported to the territory of :

Cuba, Iran, Iraq, Libya, North Korea, Sudan, Syria, Rwanda, Federal Republic of Yugoslavia.

 IXSEA	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

## SHIPPING PACK CONTENTS

You have just received your equipment in a protective carton. This contains the following items:


1. A wooden case or as an option a flightcase containing the items listed below. This enables the OCTANS unit to be protected for shipment by air.
2. The OCTANS Subsea.
3. A connector with 1,5 m cable (Subconn MCIL16F).
4. Documentation : this User Guide.
5. A CD-Rom for installation on a PC to enable the unit to be configured.
6. A Calibration Certificate.
7. A Warranty certificate.

### Verification of pack contents

You will find in the shipping case a Packing List detailing all the items referred to above. This Packing List was completed and checked by IXSEA shortly before shipment, and should logically match the contents of the pack you have received.

However, **we recommend that you check the contents of the pack and the equipment immediately on receipt of your OCTANS unit.** Specifically, you should check that all the items referred to above are present on delivery and that none has sustained damage.

If you observe any non-conformity or damage, please inform the carrier and IXSEA without delay by certified mail, describing in detail the nature of the problem.

 IXSEA	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

## 1 INTRODUCTION

Octans 1000, 3000 and 3000 Ti are members of the Octans family dedicated to underwater applications (down to 1000 m / 3000 m), featuring a specific waterproof housing in aluminium, duplex steel or titanium (10, 25 or 12kg total weight in air).

Octans is both a fibre-optic survey-grade gyrocompass and a Motion Reference Unit for marine applications that provides true-heading, roll, pitch, yaw, heave, surge, sway, rates of turn and accelerations even in highly volatile environments. Octans is also certified (in its surface unit version) to meet to the requirements of the International Maritime Organisation (IMO) for gyrocompasses. Its heart consists of a small strapdown Inertial Measurement Unit (IMU), which contains three accelerometers, three fibre-optic gyroscopes, and a real-time computer.

The fibre-optic gyroscope is a recent technology generated to meet the requirements of the aeronautical industry. It is totally inert, has no moving parts, and requires neither maintenance nor recalibration. It is capable of a very wide dynamic range and can tolerate extremely demanding mechanical environments without compromise to its performances.


Octans features the benefits of fibre-optic gyroscope technology and therefore shares the advantages of not requiring maintenance or recalibration. Its strapdown IMU structure enables straightforward, effective use with which no traditional mechanical gyrocompass can compete. Octans is insensitive to physical shock, can be carried in a case, and is easy to install. Strapdown equation processing enables the system to find North in less than 5 minutes whatever the sea conditions may be. Notably, it can be powered up at sea, which is impossible with a conventional gyrocompass.

In addition, Octans consumes only a small amount of power and directly outputs binary data to NMEA 0183 standard, which can be reconfigured if desired, in addition to analogue data allowing easy interfacing with most available repeaters.

This document briefly describes how a subsea Octans works, and provides in more detail all the possible interfaces which can be configured.

## 2 TECHNICAL DESCRIPTION

Octans is a strapdown IMU that contains three fibre-optic gyroscopes in the 0.05°/hour class, three milli-g accelerometers, and a real-time DSP computer. Figure 1 shows the Octans unit “open”.




**Figure 1 : Subsea Octans unit opened**

Dimensions and physical characteristics are given in appendix [A].

The unit's computer is a Digital Signal Processor (DSP) chip enabling rapid and complex real-time computation. This computation relates particularly to angle integration using quaternion algebra, a heading search algorithm and Coriolis force correction for vessel speed.

The heading search algorithm is specific to IXSEA and is suited to use with a strapdown IMU. It enables the heading to be sought whether the system is in movement or not and without an external reference point. It is

 IXSEA	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

based on (filtered) measurement of shifts in local gravity as the Earth rotates. This is possible because, in relation to an inertial reference frame, local gravity moves within a cone whose axis is related to the direction of the Earth's rotational vector (its North-South axis). Monitoring the movements in local gravity enables the axis of the cone to be determined and therefore the direction of geographical North. More detail on the algorithm used is given in appendix B.

### 3 MECHANICAL INTERFACE

The Octans 1000, 3000 and 3000Ti is installed using six M6 screws (Aluminium, Duplex and Titanium) on the base plate of the unit (see figure 2 and 3). Alignment is carried out by means of two centering pins located on the bottom plate of the system, enabling precise “point/line” positioning. These pins are located on the Octans Subsea centerline as shown by grooves on the base plate of the unit. The mechanical tolerance in the manufacture of Octans bottom plate allows to have 0,01° of accuracy on the centreline of the unit.

**NOTE: Useable configuration**

1000 and 3000 meters subsea units are designed as a standard for use on a vertical configuration.  
 For a subsea use in a horizontal configuration, please consult IXSEA .




Figure 2 : Subsea Octans bottom plate mounting diagram

## 4 ELECTRICAL INTERFACE

### 4.1 Description of the top panel

All Octans Subsea inputs/outputs are made via a 16-pin SUBCONN connector. The reference of the connector is MCBH16M.




Figure 3 : Subsea Octans top panel


## 4.2 Listing of interfaces

The 16-pin connector fitted on subsea Octans is used to provide the following:

1. Power supply, described in 4.4,
2. Repeater and configuration port (only RS232 level), described in 4.5,
3. 4 analogue Outputs described in 4.6,
4. 1 Serial Input/Output RS232/422 user-configurable, described in 4.7,

## 4.3 Description of the 16-pin connector


The pin out of the Octans Subsea connector is shown below:



Pin	Signal	Pin	Signal
1	VDC (20 V to 30 V)	9	AnaOutCSig
2	GROUND	10	SerGnd
3	SerOutV+/232	11	AnaOutDSig
4	SerOutV-	12	ConfigIn-
5	SerInV+	13	AnaOutBSig
6	SerInV-	14	ConfigIn+
7	AnaOutASig	15	ConfigOutV+
8	AnaOutGnd	16	ConfigOutGnd



#### 4.4 Power supply (pins 1, 2)




Octans is powered with a standard 24 V DC supply. It is possible however to supply power at any voltage between 20 V and 30 V. Maximal power consumption is 12 W in all cases. Octans does not possess an on/off switch. As soon as it is powered, it begins to seek geographical North.

**NOTE: IMPORTANT**


Please remember that any interruption of the power supply, even brief, will return the system to its initial condition and it will begin to seek North again.

### 4.5 Configuration and display output (pins 12, 14, 15, 16)



The pins 12, 14, 15, 16 are used to link the subsea Octans directly to IXSEA Octans *Repeater Software*. In order to install, configure Octans or to use the Octans *Repeater Software*, please connect your subsea Octans to a PC using a standard SUB D9 connector.


The cable between Octans and the PC has to be as follows :



## 4.6 Analogue Outputs (pins 7, 8, 9, 11, 13)

Four analogue  $\pm 10$  V outputs are available and can be user configured (signal, sampling frequency, and scale factor). For more details, please refer to the *Octans Repeater Software* user guide.

These outputs offer 14-bit resolution at 300 Hz and are identified by the signals AnaOutGnd (pin 8) and AnaOutASig (pin 7), AnaOutBSig (pin 13), AnaOutCSig (pin 9), AnaOutDSig (pin 11).



	Signal	Gnd
A	AnaOutASig (7)	AnaOutGnd (8)
B	AnaOutBSig (13)	AnaOutGnd (8)
C	AnaOutCSig (9)	AnaOutGnd (8)
D	AnaOutDSig (11)	AnaOutGnd (8)

Note 1 : configurable analogue outputs, 14 bits /  $\pm 10$ V.

## 4.7 Digital Input/Output (pins 3, 4, 5, 6 and 10)

One serial input and one serial output are available on the subsea Octans. The serial I/O can be user configured. For more details, please refer to the *Octans Repeater Software* user guide. **Please note that only the port A can to be selected.**


With the installation and configuration software each I/O, configuration parameters include:

Please refer to the *Repeater software* user guide for more details

- Electrical levels : RS 232 or 422 (see detailed pinout hereafter),
- Parity: No parity, Even parity or Odd Parity,
- Number of bits: 0.5, 1, 1.5, or 2 stop bits,
- Data transmission rate: from 600 Bauds to 115.2k,
- Protocol: Protocols based on NMEA 0183, ASCII or Binary,
- Output frequency: 0.1 Hz to 100 Hz.

### 4.7.1 RS 232 Input / Output

In RS 232, the following pinout is used:




	OutGnd	Out /+232	InGnd	In /+232
A	SerOutGnd (10)	SerOutV+/232 (3)	SerInV- (6)	SerInV+ (5)

**Note 1 :** It is possible to connect the OutGnd to the InGnd pins to allow the use of 1 single Sub D9 connector for I/O,

**Note 2 :** SerOutGnd is internally connected to ConfigOutGnd and AnaOutGnd

### 4.7.2 RS 422 Input/ Output

In RS 422, the following pinout is used:



	OutGnd / InGnd	Out /+422	Out /-422	In /+422	In /-422
A	SerOutGnd (10)	SerOutV+/232 (3)	SerOutV- (4)	SerInV+ (5)	SerInV- (6)

Note 1 : SerOutGnd is internally connected to ConfigOutGnd and AnaOutGnd

## 5 OPERATIONAL CONSIDERATIONS

All gyrocompasses, Octans included, are sensitive to the speed of travel of the vessel and current latitude. However these errors are small and as described below, latitude needs to be entered in Octans only if the ship changes latitude very substantially, and very precise speed measurement is not imperative.

### 5.1 Heading error due to the speed log

The heading output of all gyrocompasses is sensitive to the speed of travel of the vessel towards North. The international standard (ISO 8728) defines that:

*“Course error in degrees for a gyrocompass aligned north-south is determined by the formula  $V/5\pi$  x the secant of the latitude, where V is the North component of the speed in knots”.*

This speed correction applies whatever the technology used in the gyroscopes: Indeed, the linear speed of a boat travelling on the terrestrial “sphere” produces, with respect to the Earth and therefore with respect to the inertial frame of reference, a rotational speed  $V/R$ , where R is the radius of the Earth. This effects the measurement of the speed of rotation of the Earth and therefore the detection of North.

Using the above formula, it is easy to compute the speed at which the heading will begin to demonstrate an error, if the accuracy of the heading measurement is known: Octans has a dynamic accuracy of  $\pm 0.2$  degree x secant of latitude and therefore the speed in knots at which an error greater than this appears is  $V_{North_{max}} = 0.2 \times 5\pi \approx 3,2$  knots.


Even though this is a relatively low value, it is generally recommended to enter the speed in Octans to allow the unit to compensate automatically and indicate the correct heading. It can be seen from the above formula however that the speed needs to be known only to a few knots. In practice, a log which gives the speed of the vessel in relation to the water without intrinsically taking into account the surface currents is more than satisfactory for such compensation. Since all ships are equipped with GPS, we recommend sending the GPS speed frame to Octans.

## 5.2 Incorrect latitude data

### 5.2.1 Amplitude of error due to latitude data

Gyrocompasses are intrinsically sensitive to latitude. Heading error is itself dependent in general terms on the secant of the latitude, which is fairly logical: the error tends theoretically toward infinity when the gyrocompass approaches one of the geographical Poles. However, it is not this error which is considered here, but rather intrinsic system inaccuracy when it has unreliable data for the latitude of the current location.

Octans needs to know the latitude of its location in order to find geographical North rapidly. If the latitude information input is incorrect, Octans will produce an error. **This error is nevertheless very small:** The curve in the figure 4 shows the heading error in degrees multiplied by the secant of the latitude versus the latitude of the current location, assuming that the latitude entered in the Octans unit is incorrect by one degree.



**Figure. 4 : Heading error in degrees by secant of latitude**

(for a 1 degree latitude error)

Example: at 40° latitude, an error of 3° in the latitude will cause  $3 \times 0,02 = 0,06^\circ$  sec. Lat error.

### 5.2.2 Sensitivity to unreliable latitude data

In practice, Octans needs to know the latitude only to an accuracy of a 3 degrees at 45 degrees latitude. This dependency is more important at low latitudes and it is recommended below 30° to enter the current latitude in the system with at worst a 1° accuracy.

In practice, it is possible to enter the latitude directly to Octans by using a GPS NMEA sentence. You can also manually enter the latitude, please refer to the *Octans Repeater Software user guide*.



## 6 COMPUTATION OF HEAVE, SURGE, AND SWAY

### 6.1 Definition of heave, surge, and sway

The heave, or vertical motion of the vessel, is determined by the double integration of the vertical acceleration. Unfortunately, the vertical acceleration is measured with small bias due to the physical limitations of the sensors. Because of this bias component, the double integration, which represents vertical position, can diverge to infinity very quickly. The best solution, used in every motion sensor, is to use a high-pass filter, which nulls out the bias component effect. By definition, the vertical amplitude of a movement which is filtered to cut-off the frequency around zero, is called "Heave". Respectively, the two horizontal positions filtered to cut-off the frequency around zero, the *surge* and the *sway*.

### 6.2 Axis directions for heave, surge and sway measurements

#### 6.2.1 General





Figure 5 : Axis directions for the heave, surge, and sway measurements

	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

## 6.2.2 Sign conventions

The axis directions are defined as follows :

- The heave is by default defined positive up on a vertical axis pointing to the direction of the connector.
- The surge is by default defined positive on a horizontal axis parallel to the centerline pointing to the direction of the circle located on the base plate.
- The sway is by default defined positive on a horizontal axis pointing to the left of the subsea Octans (on the port side of the vehicle, if the unit is “correctly” mounted).

## 6.3 Description of the heave filter

Since the heave (surge and sway) output is high-pass filtered, the output will always return to zero when Octans is static. The heave filter has been redesigned and is now automatically configured in terms of time constant: there is no need for the user to input any parameter.

Heave filter is initialized each time OCTANS is re-started. The duration of the heave initialization phase is roughly 5 minutes, and follows the 5 mn OCTANS alignment phase. Hence, heave, surge and sway deliver accurate value after a total initialization phase of roughly 10 minutes.

Once the heave filter has been automatically initialized, it will respond to variations of OCTANS positions in the three directions (heave, surge and sway) defined in Figure 6.

After experiencing a step change in vertical position, OCTANS heave output will gradually return to zero within 1 to 2 minutes.

If Octans is moved following a sine or a combination of sinus, as usually observed with swell movements, the heave (surge and sway) output will follow this movement, for swell periods up to 30 seconds.

## 6.4 Use of lever arms for heave computation

### 6.4.1 Multiple lever arms

Octans is able to calculate the heave of an external monitoring point. Effective from firmware 4.1, three “secondary” monitoring points have been added. For each one of those secondary monitoring points, data can be output with a completely different setting including serial or analogue I/O. In particular, at each location, a different protocol can be set. This allows, for instance, driving a multibeam on one side of a vessel, to drive a single beam echo sounder at another location, to send analogue heave info to a sub-bottom profiler.




Figure 6 : Subsea Octans lever arm reference point





Figure 7: Multiple lever arms monitoring

## 6.4.2 Effect of a lever arm on the computation of heave

Octans can be located some distance away from the desired monitoring point. In this case, the heave at the monitoring point can be very different from the one at the subsea Octans, due to the lever arms.

Let us assume for example that the heave of the subsea Octans is null, but there is just a pitch angle. If there is a lever arm between Octans and the desired monitoring point in the direction of the subsea Octans, it is easy to see that the heave of the monitoring point is not null, but equal to the tangent of the pitch angle times the lever arm distance (see figure 8).



**Figure 8 : Effect of lever arms**

To avoid this effect, it is recommended to place the subsea Octans as close as possible to the monitoring point.

Otherwise, it is possible to compensate the effects of lever arms by computation. To perform this computation, it is necessary to know the exact position of the monitoring point in the frame of the subsea Octans. It is possible to give the vector  $( X_1 , X_2 , X_3 )$  to Octans using the *Repeater Software*. The definition of this vector follows (see figure 9, next page).





Figure 9 : Definition of the lever arms vector for heave computation

## 7 TRUE HEADING, ROLL AND PITCH

The true heading is the angle between the vertical plane oriented in the North direction and the vertical plane passing through the subsea Octans. The vertical plane passing through Octans is visualized by the centreline, **oriented positive from the oval-shaped hole towards the circular-shape hole located on the bottom plate.**


The orientation of this angle is given in figure 10.



**Figure 10 : Definition of true heading**

### 7.1 Roll


The roll is the angle between the horizontal plane and the axis 2 of the subsea Octans. This angle is default defined positive in the direction of axis 1, i.e. when the vehicle's port side is up.



**Figure 11 : Definition of roll**

## 7.2 Pitch

The pitch is the angle between the horizontal plane and the axis 1 of the subsea Octans. This angle is default defined positive in the direction of axis 2, i.e. when the vehicle's bow is down.



**Figure 12 : Definition of pitch**



## APPENDIX A-SPECIFICATION

### 1. TECHNICAL DESCRIPTION

Octans in an IMO-compliant survey-grade gyrocompass and an integral motion sensor at the same time.

#### 1.1. Performance

##### Gyrocompass Technical Performance

Dynamic accuracy (whatever sea-state)	$\pm 0.2^\circ$ Secant Latitude (*) or $0.1^\circ$ RMS
Settle point error	$\pm 0.1^\circ$ Secant Latitude or $0.05^\circ$ RMS
Settling time (static conditions)	1 Minute
Settling time at sea :	3 Minutes
Repeatability	$\pm 0.025^\circ$ Secant Latitude
Resolution	$0.01^\circ$
No Latitude limitation	
No speed limitation	

(\*) Secant Latitude =  $1/\cosine$  Latitude

##### Motion Sensor Technical Performance

Heave, Surge & Sway :	
Accuracy	5 cm or 5% (whichever is highest)
Resolution	1 cm
Heave motion periods	0.03 to 100 s (tuneable)
Roll, Pitch & Yaw :	
Accuracy	$0.01^\circ$
Range	No limitation
Follow-up speed	Up to $500^\circ/s$

## 1.2. Environmental specifications

Operating temperature :	-40°C to +60°C
Storage temperature :	-40°C to +80°C
Shocks :	30 g in 6 ms (operating) 50 g in 11 ms (survival)
Vibrations :	1 g sine (5 to 50 Hz)
MTBF	30 000 Hours

## 1.3. Interface

### 1.3.1 Power Requirement

Input voltage : 20 to 30 V d.c. (24 V nominal)

Power consumption : 12 W (max.)

### 1.3.2 Outputs

- Serial: 3 independent and configurable digital outputs (Surface Octans)  
Or 1 configurable digital output (Subsea Octans)

To be selected from a complete set of existing protocols (NMEA 0183, TSS, Seatex, Simrad, Robertson, Tokimec, Anschutz Compatible) or any custom protocol, with RS 232 or RS 422 levels

- Analogue: 4 independent and configurable analogue outputs, 14 bits /  $\pm 10V$ , (Surface Octans, Subsea Octans),
- Pulses
- Update rate: up to 100 Hz

### 1.3.3 Inputs

- Serial: 3 independent and configurable digital inputs (Surface Octans),  
Or 1 configurable digital input (Subsea Octans)
- Analogue: 2 independent and configurable analogue inputs, 16 bits /  $\pm 15 V$  (Surface Octans only)

- Pulses
- Update rate : up to 100 Hz

### 1.3.4 Repeater Software

Octans is delivered with a powerful and easy-to-use Repeater software, which allows a complete configuration (choice of baud-rates and frequencies, data frame protocols, scale factors for analogue I/O, multiple lever arms, filtering parameters....).

## 1.4. Housings

### 1.4.1. Surface unit

Shape :	Rectangular box, splash proof(IP 66)
Dimensions (L x W x H, in mm) :	280 x 136 x 149,5
Weight in air :	4.8 kg
Material :	Aluminium

### 1.4.2. Subsea units

#### ***OCTANS 1000, built in an underwater housing (1000-meter depth rated)***


Shape :	Cylinder
Dimensions (Ø x H, in mm) :	209 x 318 (Ø body = 179)
Weight in air :	10 kg
Weight in water :	2 kg
Material :	Aluminium (hard anodising)

#### ***OCTANS 3000, built in an underwater housing (3000-meter depth rated)***

Shape :	Cylinder
Dimensions (Ø x H, in mm) :	209 x 318 (Ø body = 179)
Weight in air :	25 kg
Weight in water :	17 kg
Material :	Stainless steel (duplex)

#### ***OCTANS 3000 Ti, built in an underwater housing (3000-meter depth rated)***

Shape :	Cylinder
---------	----------

	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

Dimensions (Ø x H, in mm) : 209 x 322 (Ø body = 173)  
Weight in air : 12 kg  
Weight in water : 5 kg  
Material : Titanium

***OCTANS 6000, built in an underwater housing (6000-meter depth rated)***

Shape : Cylinder  
Dimensions (Ø x H, in mm) : 180 x 334  
Weight in air : 18 kg  
Weight in water : 9 kg  
Material : Titanium  
Configuration : horizontal (cradle recommended)

**1.4.3 Useable configuration**

All Octans subsea units, excepted 6000 meters, are designed as a standard for use on a vertical configuration.

**2. CERTIFICATION**

Octans complies with the regulations of the International Maritime Organisation resolutions A.424 (XI), A. 694 (17), A.183 (19) for gyrocompasses, with SOLAS 74 as amended (regulations V/12 (d), (i)) and IEC 60945, IEC 61162-1 and ISO 8728.

Octans surface has been awarded certificate N° 09807/A0 EC from certifying authority N° 0062. A copy of all relevant documentation is available upon request to IXSEA.

## APPENDIX B - PHYSICAL PRINCIPLES OF OCTANS

Extract from

“highly compact fiber optic gyrocompass for applications at depths up to 3,000 meters,  
presented at the Underwater Intervention 2000 show, January 2000”

### 1. THE TECHNOLOGY OF FIBRE OPTIC GYROSCOPES (FOGs)

FOGs do not use the rapidly spinning top employed in mechanical gyroscopes – in fact, they have no moving parts at all. They do not use the gyroscope effect to measure the rotational speeds of mobiles, but a radically different phenomenon – the so-called “Sagnac Effect”.

#### 1.1. The Sagnac Effect

The Sagnac Effect is a physical phenomenon of relativistic type; understanding it requires a good grasp of Special Relativity. However, it is possible to provide a simplified (although inaccurate) physical interpretation of the effect. Imagine a coil of optical fiber. Optical fiber, as is well known, is a good vector for the propagation of light. This coil will in principle have two exits at the two ends of the fiber. If we inject a light pulse into one end, it will come out at the other after a duration equal to the time the light takes to cover the entire length of the coiled fiber. If we now inject two pulses simultaneously into the two ends of the coil, they will travel in opposite directions, pass each other in the middle and come out at opposite ends of the coil. The time the light takes to travel through the coil will be the same irrespective of its direction of travel, and the two pulses will therefore exit the fiber at the same time. If we now imagine that the coil is rotating around its central axis, this movement will “help” one pulse but “hold back” the other. It can be seen therefore that the two pulses will leave the coil at different times. If we measure this temporal difference, we can deduce from it the speed of rotation.

#### 1.2. FOG description and performance

In practice, this difference is determined in optics using interferometry, which provides a measurement of the phase difference between the two light waves traveling in opposite directions within the coil. The interferometer is created by “closing” the coil on itself using an optoelectronic component called an “Integrated Optical Circuit” (see figure B1).



**Figure B1 : The “heart” of a FOG  
the optical fiber coil with its integrated optical circuit**

The ingenious signal processing which follows requires a large number of optoelectronic components if the information on optical phase, carrying information on rotation, is to be converted into a digital signal useable by a calculator.


In practice, FOG performance gets better as it gets bigger, a fact which can be easily understood in terms of the length of the coiled optical fiber: at any given rotational speed, increased length will make it easier to separate the two light pulses temporally in the way described above.

FOG performance can be measured in terms of many parameters, of which the most important is known as bias stability, which means the stability of the zero point, or the intrinsic accuracy of the measurement of rotational movement. It is usual to express bias stability in degrees per hour (deg/hour), to make comparison easier with the Earth's rotation rate, which is 15 deg/hour (1 revolution in 1 day, 360 degrees in 24 hours, giving 15 degrees per hour). In practice, in order to measure the bias stability of a FOG, we measure the Earth's rotation rate. As an example, at the latitude of Paris, France (48,57°N), a FOG must measure 11.33 deg/hour (i.e. the projection of the rotation of the Earth onto the apparent vertical).

### **1.3. Inertial Measurement Unit (IMU)**

Actually, a single FOG measures the projection of the instantaneous rotation along the main axis of its coil, and three FOGs are necessary to measure the rotation rate vector.

This triad of gyroscopes is usually combined with a set of three accelerometers. An accelerometer enables measurement firstly of the instantaneous acceleration along a given axis (and thereby, through successive integrations, speed and position), and secondly, knowledge of apparent local gravity, and thereby the local vertical axis.

 IXSEA	January 2004	MU/OCTU/009	Edition F
---	--------------	-------------	-----------

The compact assembly formed by the three gyroscopes and the three accelerometers is called an “Inertial Measurement Unit” (IMU) and forms the heart of any inertial reference system. When an IMU is coupled to a calculator and an interface, the result is an “inertial reference system”.

Octans is such an inertial reference system capable of providing complete information on the physical attitude of the mobile. The IMU comprises three FOGs (0.05 deg/hour bias stability) and three accelerometers ( $\pm 500\mu\text{g}$ ).

But Octans does not allow access to the raw data of its IMU heart.

## 2. THE FIBRE OPTIC GYROCOMPASS – UNDERLYING PRINCIPLES

By definition, a gyrocompass is a gyroscope-based system for the measurement of true heading, that is to say, angular measurement of a position in relation to geographical North, whatever the movements made by the object on which the gyrocompass is placed. This means for example, that the gyrocompass must remain relatively insensitive to pitch and roll movements, which may be at high levels on some ships. In this way, the gyrocompass is to be distinguished from North finders, which need to remain totally immobile in relation to the Earth when the measurement is done.


Gyrocompass types currently in use comprise a gyroscope which aligns its angular moment with that of the Earth and therefore exploit at a basic level the intrinsic properties of rotating solids, and notably the principle of gyroscopic spins. A gyrocompass using FOGs must therefore be based on a radically different concept. It is this concept that we explain below.

### 2.1. North finders

We can begin by assuming that our initial objective is to produce a “static” indicator of North, that is to say, an indicator without any mechanical system (which means that we cannot rotate a single horizontal-axis gyro in order to find the position which cancels out the signal, which will correspond to the East). In order to measure the rotation vector of the Earth  $\Omega$ , the first thing we need is three gyros for the three spatial axes. However, that is not enough yet to indicate a heading, because we lack information about the horizontality of the assembly. This information can be obtained from a plumb line, electrolytic levels or accelerometers, by making a measurement of the local gravity vector  $\mathbf{g}$ . It then remains to project the Earth rotation vector  $\Omega$  onto the horizontal plane orthogonal to  $\mathbf{g}$  to obtain the direction of geographical North (figure B2). It can be seen that the intrinsic accuracy of this measurement depends on the accuracy of the sensors (the bias of the gyros  $b_{gyro}$  and the accelerometers  $b_{acc}$  for example) and the latitude  $L$ . It can be expressed in radians as:

$$\Delta\Phi = \frac{b_{gyro}}{\Omega} \text{Sec } L + \frac{b_{acc}}{g} \tan L$$





**Figure B2: North Finder / basic concept**


To achieve a North finder capable of rivaling commercially available conventional gyrocompasses, accurate to a few tenths of a degree of the secant of the latitude, it is necessary to select gyros offering accuracy to at least one-hundredth of terrestrial rotation rate ( $15^\circ/\text{h}$ ), such as the FOG 90 ( $0.05^\circ/\text{h}$ ) produced at IXSEA, and accelerometers precise to one-hundredth of apparent gravity. In practice, the accelerometers used in Octans provide better performance than this in order to improve dynamic stability.

## 2.2. Gyrocompasses

The gyrocompass represents a step up from the above in terms of complexity. At this level, the system has to withstand random movements – which may be violent, such as a ship's pitch and roll. The difficulty is twofold compared with the previous design: firstly, measurement of terrestrial rotation is disturbed by enormously high rotational values (several orders of magnitude greater than the Earth's rotation rate), and secondly, measurement of gravity is disturbed by centrifugal accelerations which may also prove to be relatively high.

The basic idea is therefore to abandon the direct use of the measurement of the Earth's rotation rate related to the gyroscopic frame, in favor of a "fixed" reference frame, which is called the Inertial Space.

Described briefly, the system comprises three gyros and three accelerometers: the three gyros enable the rotation rate of the moving object to be measured at any given instant (including the Earth's rotation rate), and the three accelerometers give the sum of the acceleration and apparent gravity; these measurements are both related to a reference bound to the moving object itself. The angular attitude of the moving object compared to the Inertial space is then computed by integration of the rotation rate. The accelerometer data, which is the sum of the acceleration and gravity, is then expressed within the Inertial Space. After filtering out the acceleration values, it is possible to "observe" the slow drift of apparent gravity due to the rotation of the Earth. In fact, it is easy to show that the apparent gravity expressed within the Inertial Space defines a cone whose main axis is the rotational axis of the Earth (see figure B3). Examination of the movement of  $\mathbf{g}$  can therefore tell us where geographical North is without need of an external reference.



**Figure B3: Conical movement of the local gravity  $g$  in relation to the Inertial Space**